



PHYSICS

BOOKS - HC VERMA PHYSICS (HINGLISH)

OPTICAL INSTRUMENTS



1. Two boys one 52 inches tall and the other 55 inches tall, are standing at distances 4.0 m

and 5.0 m respectivley from an eye. Which boy

will taller?



2. A compound microphone has an objective of focal length 1 cm and an eyepiece of focal length 2.5 cm. An object has to be placed at a distance of 1.2 cm awy from the objective for normal adjustment. a.Find the angular magnification. b.Find the length of the microscope tube.



3. A nearsighted man can clearly see objects up to a distance of 1.5m. Calculate the power of the lens of the spectacles necessary for the remedy of this defect.

A. - 0.37D.

B. - 67D.

C. - 0.67D.

D. - 37D.





Worked Out Examples

1. An object is seen thorugh a simple microscope of focal length 12 c. Find the angular mgnification produced if the image is formed at the near pointofhe eye which is 25 cm away from it.



2. (a) An object is seen through a simple microscope of focal length 12cm. Find the angular magnification produced if the image is formed at the near point of the eye which is 25cm away from it.

(b) A 10D lens is used as a magnifier. Where should the object be placed to obtain maximum angular magnification for a normal eye (near point = 25cm)?



3. A small object is placed at distance of 3.6 cm from a magnifier of focal length 4.0 cm. a. find the position of theimage. B. find the linear magnification c. Find the angular magnification.

Watch Video Solution

4. A compound micrscope consists of an objective of focal length 1.0 cm and an eyepiece of focal length 5.0 cm separated by

12.2 c.a. At wht distance from the objective should a object be placed to focus it prope4y so that the final image is formed at the least distance of clear vision (25cm)? b. calculate the angular magnificationn in this case.

Watch Video Solution

5. The separation L between the objective (f = 0.5cm() and the eyepiece (f=5cm) of a compound microscope is 7 cm. Where should a small object be placed so that the eye is

least strained to see the image? Find the angular magnification produced by the microscope.

Watch Video Solution

6. An astronomical telescope has an objective of focal length 20 cm and an eyepiece of focal length 4.0 cm. The telescope is focused to see an object 10 cm from the objective. the final image is formed at infinity. Find the length of the tube and the angular magnification

produced by the telescope.



7. A Galilean telescope is constructed by an objective of focal length 50 cm and a eyepiece of focal length 5.0 cm a. find the tube length and magnifying power when it is used to see n object at a large distancei normal adjustment b. if the telescope is to focus an object 2.0 m away from the objective what should be the tube length and angular magnification, the

image again forming at infinity?



8. The image of the moon is focussed by a converging lens of focal length 50 cm on a plane screen. The image is seen by an unaided eye from a distance of 25 cm. Find te angular magnification achieved due to the converging lens.

9. The near and far points of a person are at 40cm and 250cm respectively. Find the power of the lens he/she should use while reading at 25cm. With this lens on the eye, what maximum distance is clearly visible?



10. A young boy can adjust the power of his eye lens between 50 D and 60 D. His far point

is infinity. A. What is the distance of his retina

from the eye-lens? b. What is the near point?



Short Answer

1. Can virtual image be formed on the retina in

a seeing process?

2. Can the image formed by a simple microscope be projected on a screen without using any additional lens or mirror?



3. The angular magnification of a system is less

than one. Does it mean that the image formed

is inverted?

4. A simple microscope using a single lens often shows coloured image of a white source. Why?



5. A magnifying glass is a converging lens placed close to the eye. A farsighted person uses spectacles having converging lenses. Compare the functions of a converging lens used as a magnifying glass and as spectacles.

6. A person is viewing an extended object. If a converging lens is placed in front of his eyes, will he feel that the size has increased?

Watch Video Solution

7. By mistake, an eye surgeon puts a concave lens in place of the lens in the eye after a cataract operation. Will the patient be able to see clearly any object placed at any distance? 8. The magnifying power of a simple microscope is given by $1 + \frac{D}{f}$, where D is the least distance for clear vision. For farsighted persons, D is greater than the usual. Does it mean that the magnifying power of a simple microscope is greater for a farsighted person as compared to a normal person? Does it mean that a farsighted person can see an insect more clearly under a microscope than a normal person?



9. Why are the magnification properties of microscopes and telescopes defined in terms of the ratio of angles and not in terms of the ratio of sizes of objects and images?



10. An object is placed at a distance of 30 cm from a converging lens of focal length 15 cm. A

normal eye (near point 25 cm, far point infinity) is placed close to the lens on the other side. (a) Can the eye see the object clearly? (b) What should be the minimum separation between the lens and the eye so that the eye can clearly see the object? c. Can a diverging lens, placed in contact with the converging lens, help in seeing the object clerly when the eye is close to the lens?



11. A compound microscope forms an inverted image of an object. In which of the following cases it is likely to create difficulties? a. Looking at small germs. b.Looking at circular spots. c. Looking at a vertical tube containing some water.

Watch Video Solution

Objective 1

1. The size of an object as perceived by an eye depends primarily on

A. actual of the object

B. distances of the object from the eye

C. aperture of the pupil

D. size of the image formed on th retina

Answer: D

2. The muiscles of a normal eye are least strained when the eye is focussed on an object

A. far away from the eyes

B. very close to the eye

C. at abot 25 cm from the eye

D. at about 1 m from the eye

Answer: A

3. A normal eye is not able to see objects closer than 25 cm because

A. the focal length of the eye is 25 cm

B. the distance of the retina from the eye

lens is 25 cm

C. the eye is not able to decreae the

distance between the eye lens and the

retina beyond a limit

D. the eye is not able to decrease the focal

length beyond a limit.

Answer: D

Watch Video Solution

4. When objects at different distances are seen by the eye, which of the following remai constant?

A. the focal length of the eye lens

B. the object distance from the eye lens

C. the radii foc curavature of the eye lens

D. the image distance from the the eye lens

Answer: D

Watch Video Solution

5. A person can clearly see objects between 25 cm and 200 cm. Which of the following may represent the range of clear vision for a person B having muscles stronger than A bull all other parameters of eye identicl to that of

Α

A. 25 cm to 200 cm

B. 18 cm to 200 cm

C. 25 cm to 300 cm

D. 1 cm to 300 cm

Answer: B

6. The focal length of a normal eye lens is about

A. 1 mm

B. 2 cm

C. 25 cm to 300 cm

D.1m

Answer: B

7. The distance of the eye lens from the retina is x. For a normal eye, the maximum focal length of the eye lens

A. = xB. < x

 $\mathsf{C.} > x$

D.
$$= 2x$$

Answer: A



8. An object is placed at a distance u from a simple microscope of focal length f. The angular magnifiction obtaioned depends

A. on f but not on u

B. on u but not on f

C. on f as well as u

D. neigher on f nor on u

Answer: C

9. To increase the angular magnification of a simple microscope, one should increase

A. the focal length of the lens

B. the power of the lens

C. the apeture of the lens

D. the object size

Answer: B

1. A man weasring glasses of focal length +1 m cannot clearly see beyond 1 m

A. if he is farsighted

B. if he is nearsighted

C. if his vision is normal

D. in each of these cases

Answer: D

View Text Solution

2. A man is looking at a small object placed at his near point. Without altering the position of lhis eye or the object, he puts a simple microscope of magnifying power 5x before his eyes. The angular magnification achieved is

A. 5

B. 2.5

C. 1

D. 0.2







1. When we see an object the image formed on

the retina is

A. real

B. virtual

C. erect

D. inverted.

Answer: A::D

Watch Video Solution

2. In which of the following the final image is erect?

A. simple microscope

B. compound microscope

C. Astronomical telescope

D. Galilean telescope

Answer: A::D

Watch Video Solution

3. The maximum focal length of the eye lens of a person is greater than its distance from the retina. The eye is

A. always strained in looking at an object

B. strained for objects at large distances

only

C. strained for objects at short distances

only

D. unstrained for all distances

Answer: A

4. The focal length of the objective of a compound microscope is f_0 and its distance from the eyepiece is L. The object is placed at a distance u from the objective. For proper working of the instrument.,

A. L < uB. L > u

C. $f_0 < L < 2 f_0$

D. $L>2f_0$

Answer: B::D

Watch Video Solution

Objective 2

- 1. Mark the correct options.
 - A. if the far point goes ahead, the power of the divergent lens should be reducedB. if the near point goes ahead, the power of the convergent lens should be reduced.

C. If the fr points 1 m away form the eye,

divergent lens should be used.

D. If the near point is 1 m away from the

eye, divergent lens should be used

Answer: A::C

View Text Solution

Exercises

1. An object is to be seen through a simple microscope of focal length 12 cm. Where should the object be placed so as to produce maximum angular magnification? The least distance for clear vision is 25 cm.

Watch Video Solution

2. A simple microscope has a magnifying power of 3.0 when the image is formed at the near point (25 cm) of a normal eye. (a) What is

its focal length? (b) What will be its magnifying power if the image is formed at infinity?

Watch Video Solution

3. A child has near point at 10 cm. What is the maximum angular magnification the child can have with a convex lens of focal length 10 cm?

4. A simple microscope is rated 5 X for a normal relaxed eye. What Nvill be its magnifying power for a relaxed farsighted eye whose near point is 40 cm?

Watch Video Solution

5. Find the maximum magnifying power of a compound microscope having a 25 diopter lens as the objective, a 5 diopter lens as the eyepiece and the separation 30 cm between

the two lenses. The least distance for clear

vision is 25 cm.



6. The separation between the objective and the eyepiece of a compound microscope can be adjusted between 9.8 cm to 11.8 cm. If the focal lengths of the objective and the eyepiece are 1.0 cm and 6 cm respectively, find the range of the magnifying power if the image is always needed at 24 cm from the eye.



7. An eye can distinguish between two points of an object if they are separated by more than 0.22 mm when the object is placed at 25 cm from the eye. The object is now seen by a compound microscope having a 20 D objective and 10 D eyepiece separated by a distance of 20 cm. The final image is formed at 25 cm from the eye. What is the minimum separation between two points of the object which can now be distinguished?

8. A compound microscope has a magnifying power of 100 when the image is formed at infinity. The objective has a focal length of 0.5 cm and the tube length is 6.5 cm. Find the fbcal length of the eyepiece.

> Watch Video Solution

9. A compound microscope consists of an objective of focal length 1 cm and an eyepiece

of focal length 5 cm. An object is placed at a distance of 0.5 cm from the objective. What should be the separation between the lenses so that the microscope projects an inverted real image of the object on a screen 30 cm behind the eyepiece?

O Watch Video Solution

10. An optical instrument used for angular magnification has a 25 D objective and a 20 D eyepiece. The tube length is 25 cm when the

eye is least strained. a. Whether it is a microsciAn optical instrument used for angular magnification has a 25 D objective and a 20 D eyepiece. The tube length is 25 cm when the eye is least strained.e or a telescope? b. What is the angulasr magnificant produced?

View Text Solution

11. An astronimical telescope is to be designed

to hve a magnifying power of 50 in normal

adjustment. If the length of the tube is 102 cm,

fid the powers of the objective and the eyepiece.

Watch Video Solution

12. The eyepice of an astronomicasl telescope has a focasl length of 10 cm. The telescope is focussed for normal vision of distant objects when the tube length is 1.0 m. find the focal length of the bjective and the magnifying power of the telescope.



13. A Galilean telescope is 27 cm long when focussed to form an image at infinity. If the objective has a focal length of 30 cm, what is the focal length of the eyepiece?



14. A farsighted person cannot see objects placed closer to 50 cm. Find the power of the lens needed to see the objects at 20 cm.



15. A nearsighted person cannot clearly see beyond 200 cm. Find the power of the lens needed to see objects at large distances.



16. A person wears glasses of power -2.5D. Is

the person short sighted or long sighted ?

What is the far point of the person without

glasses ?



17. A professor reads a greeting card received on his 50th birthday with + 2.5 D glasses keeping the card 25 cm away. Ten years later, he reads his farewell letter with the same glasses but he has to keep the letter 50 cm away. What power of lens should he now use?



18. A normal eye has retina 2 cm behind the eye-lens. What is the power of the eye-lens when the eye is (a) fully relaxed, (b) most strained?

Watch Video Solution

19. The near point and the far point of a child are at 10 cm and 100 cm. If the retina is 2.0 cm behind the eye-lens, what is the range of the power of the eye-lens?



20. A nearsighted person cannot see beyond 25 cm. Assuming that the separation of the glass from the eye is 1 cm, find the power of lens needed to see distant objects.

Watch Video Solution

21. A person has near point at 100 cm. What power of lens is needed to read at 20 cm if

he/she uses (a) contact lens, (b) spectacles having glasses 2.0 cm separated from the eyes?

Watch Video Solution

22. A lady uses + 1.5 D glasses to have normal vision from 25 cm onwards. She uses a 20 D lens as a simple microscope to see an object. Find the maximum magnifying power if she uses the microscope (a) together with her glass (b) without the glass. Do the answers suggest that an object can be more clearly seen through a microscope without using the correcting glasses?

Watch Video Solution

23. A lady cannot see objects closer than 40*cm* from the left eye and closer than 100*cm* from the right eye. While on a mountaining trip, she is lose from her team. She tries to make an astronomical trip, from her reading glasses to look from her teammates. (a) Which glass

should she use as the eyepiece? (b) What

magnification can she get with relaxed eye?

